



Automated Pure Water Product Instructions

Installation of Retention Tanks and Sand Traps

Before Installation:

- 1 - Locate **Black In/Out Head** from carton and install center shaft
- 2 - Glue **Gray Mushroom** (PVC Glue) on bottom of center shaft
- 3 - Install **Head Assembly** into tank

NOTE: A 1" threaded nipple (8" long) works very well as a lever handle to tighten head assembly.



Installation:

NOTE: For best results use "white Teflon pipe dope" on threaded In/Out adapters into head assembly.

- Set unit in position with In and Out lined up. At this time determine where the drain should be in relationship to the In and Out lines. If necessary, rotate base and bottom drain to proper place for customer to drain tank and install 3/4" drain for blow-down.

NOTE: The base can be removed and repositioned, it snaps on, not glued.

- After unit is plumbed in, fill slowly with a valve open, to relieve air from tank.



WARNING!

Hand tighten drain line assembly ~ use of wrench will cause damage. Elbow swivels on the o-ring.



IMPORTANT! Instruct customer on flushing tank every 10 to 60 days for 3 to 5 minutes.

NELSEN

C O R P O R A T I O N

3250 Barber Road
Norton, OH 44203
Phone: 800.362.9686
Fax: 888.544.8780

14035 W. El Cielo
Goodyear, AZ 85338
Phone: 866.445.4299
Fax: 602.442.0447

4410 E Adamo Dr Suite 102
Tampa, FL 33619
Phone: 813.712.2270
Fax: 813.712.2274

1012 Assembly Circle - # 100
Schertz, TX 78154
Phone: 855.674.0357
Fax: 210.714.2571

NelsenCorp.com Commercial.NelsenCorp.com VestaWater.com